



Description

Living Proof Silk Semi Gloss is the breakthrough in acrylic technology that combines the serviceability and resistance properties of traditional turps based enamels with the convenience and reduced odour of water based finishes. It can be used in every room of the home on walls and trim and its specially hardened, stain resistant, non yellowing resin system achieves new standards in water based finish performance. Living Proof Silk Semi Gloss resists dirt, stains and scuffing and also makes the surface easy to clean.

Uses

Interior walls/trim for high traffic areas. Walls and trim in all interior areas of the house, but most particularly those subjected to maximum wear and abuse such as high traffic corridors and foyers. Not recommended for use in two coat systems on new work.

Recommended for

Highest serviceability and stain resistance.

Features

Advanced Flow Modifiers

Ease of application, good flow, minimal roller splatter

Contains Teflon Micropowder

Superior serviceability, washability, stain and burnish resistance.

Low Odour

Ideal for repainting air conditioned buildings

Special Resin System

Low flame spread compliance suitable for commercial use - tested to AS1530.3

Water Based

Low residual odour during drying

Technical

Colour Range

Extensive colour range. Refer to Taubmans Consumer or Architectural/Specifier Colour Systems.

Drying And Recoating

Normally dries in 30 minutes and may be recoated after 2 hours (at 25°C and 50% relative humidity). Note - Drying time may be lengthened in damp, cold or humid conditions.

Gloss Level

Semi Gloss (25%) as per AS2311

Odour

Ensure adequate ventilation during use.

Specifications met

APAS 0260/2, AS3730.2

Washability

Excellent

Early Fire Hazard Properties - AS1530.3

Ignitability Index 0 Spread of Flame Index 0 Heat Evolved Index 0 Smoke Developed Index 2

Surface Preparation

New/Bare Work

Seal bare wallboards and timber with Taubmans 3 in 1.

Repaint

Remove all loose and flaking paint. Wash to remove dirt, grease, wallpaper paste and kalsomine. Seal kalsomine residue, undercoat aged enamel and seal stripped wallpaper areas with PrepRight Traditional Undercoat to assist adhesion. Fill holes and cracks with a suitable filler, sand smooth and seal with Taubmans 3 in 1. If mould is present, treat surface with bleach.

Application

Not recommended for use in two coat systems on new work. Do not use abrasive cleaners on the paint finish or expose it to excessive steam in the first 48 hours. Remove dirt and grime with a soft cloth, warm water and mild liquid detergent. Pat dry with a soft cloth.

Application

Apply two liberal coats with a quality brush, roller or spray. A 10mm regular nap roller cover is recommended. Spread paint evenly but do not overspread. Provide adequate ventilation during use.

Cleanup

Water

Coverage

Up to 16m²/litre. Coverage will be lower on rough or absorbent surfaces.

Recoat

Recoat after 2 hours at 25°C and 50% relative humidity.

Stirring

Stir paint with a 25mm wide flat stirrer in a circular lifting motion for at least 5 minutes before use.

Temperature

Do not use at temperatures below 10°C, above 35°C or when humidity is above 85%.